



Unit Arm / Bearings (for Procenter Console)





Unit Arm / Bearings (for Procenter Console)		
Item	Description	Qty.
1	Console Mtd. Unit Arm / Bearings <i>(includes items 2 thru 14)</i>	1
2	• Unit Arm Kit <i>(includes items 2 & 3)</i>	1
3	•• Needle Bearing	2
4	•• Slotted Bearing Sleeve	1
5	• Dowel Pin	4
6	• Set Screw	2
7	• Bearing Washer	1
8	• Console Bearing Assembly <i>(includes items 9 thru 13)</i>	1
9	•• Screw	4
10	•• Bearing Housing	1
11	•• Iglide Bearing	1
12	•• Set Screw	2
13	•• Needle Bearing	1
14	• Trim Ring	1

Page Applies To:	Mounted to:	Delivery System Serial Numbers:
Console Mtd. Delivery Units	Ultra / Elevance Chairs	all