



LR Unit Arms (Elevance Chairs)

Common Components..... 004-0859-99

Includes: Connectors, tubing, syringes,
umbilicals, HVE / saliva ejectors




DA3202i



LR Unit Arm (Elevance Chairs)		
Item	Description	Qty.
1	LR Unit Arm Assembly (includes items 2 thru 7)	1
2	• Needle Bearing	2
3	• Slotted Bearing Sleeve	1
4	• Dowel Pin	2
5	• Set Screw	2
6	• LR Unit Arm Kit (includes items 2 & 3)	1
7	• Refer to: " Water Bottle Assembly (LR) "	1
8	Flange Bearing	1
9	Greased Bearings Kit	2
10	Bearing Cap	1
11	Bolt	1

Page Applies To:	Mounted to:	Delivery System Serial Numbers:
LR Delivery Units	Elevance Chair	V806684 thru Present



DA2935i

Water Bottle Assembly (LR)		
Item	Description	Qty.
1	LR Water Bottle Assembly (incl. items 2 thru 9)	1
2	• Bottle Cover	1
3	• Screw	2
4	• Bottle Cap Assembly (includes items 5 & 6)	1
5	•• O-Ring	1
6	•• Tubing (sold per ft.)	1
7	• Bottle	1
8	• Toggle Switch Assembly	1
9	• Double Sided Tape	AR
10	Gasket (s/n: NV1000 thru NV4132 only)	1

Page Applies To:	Mounted to:	Delivery System Serial Numbers:
LR Delivery Units	<i>Ultra / Elevance Chairs</i>	<i>all</i>