



Console Mtd. Unit Arm / Bearings		
Item	Description	Qty.
1	Console Unit Arm Assembly <i>(includes items 2 - 9)</i>	1
2	• Needle Bearing	2
3	• Slotted Sleeve Bearing	1
4	• Set Screw	1
5	• Unit Arm Assembly	1
6	• Cap Screw (Socket Head)	1
7	• Trim Ring	1
8	• Washer	1
9	• Console Bearing Assembly <i>(includes items 10 - 14)</i>	1
10	• Needle Bearing	1
11	• Cap Screw (Socket Head)	5
12	• Housing	1
13	• Set Screw	1
14	• IGlide Bearing	1

Page Applies To:	Mounted to:	Delivery System Serial Numbers:
Console Mtd. Delivery Units	Elevance Chairs	all